

PLAN DE FREQUENCES

N°	Station	Canal	Fréquence	N°	Station	Canal	Fréquence
201	NOSTALGIE	41	634	224	FRANCE MUSIQUE	44	658
202	RIRE & CHANSONS	41	634	225	FRANCE INFO	44	658
203	FIP	41	634	226	FRANCE INTER	44	658
204	RFI INT	41	634	227	FRANCE BLEU	44	658
205	RADIO CLASSIQUE	41	634	228	EUROPE 1	44	658
206	RMC	41	634	229	RTL	45	666
207	JAZZ RADIO	41	634	230	SUD RADIO	45	666
208	BBCW SERVICE	41	634	231	TSF JAZZ	45	666
209	FUN RADIO	41	634	232	BFM BUSINESS	45	666
210	LE MOUV	41	634	233	NRJ	45	666
211	RADIO DJ FG	41	634	234	VIRGIN RADIO	45	666
212	VIBRATION	41	634	235	RTL 2	45	666
213	CONTACT FM	41	634	236	SKYROCK	45	666
214	RADIO LATINA	41	634	237	NOVA	46	674
215	VOLTAGE	41	634	238	RFM	46	674
216	OUI FM	44	658	239	CHERIE FM	46	674
217	ADO	44	658	241	BBC ARABIC	46	674
219	RADIO NOTRE DAME	44	658	242	RFI MULTILINGUE	46	674
220	RADIO ALPHA	44	658	243	FRANCE CULTURE	46	674
221	RCJ/SHALOM	44	658	244	FRANCE BLEU ALSACE	38	610
222	BEUR FM	44	658	245	FRANCE BLEU SUD LORRAINE	38	610
223	RADIO COURTOISIE	44	658	246	FRANCE BLEU LORRAINE NORD	38	610